





NOTES:

- 1) MATERIAL: N/A
- 2) FINISH: POWDER COAT GREEN SANDTEX (4.3.5.8) PER DART QSI 005 4.3
- 3) TOLERANCES: PER DART QSI 018 UNLESS OTHERWISE NOTED
- 4) UNITS: INCHES UNLESS OTHERWISE NOTED
- 5) BREAK SHARP EDGES: 0.005 TO 0.010 MAX
- 6) IDENTIFICATION: N/A
- 7) WEIGHT: 1.01 lbs
- 8) PRIOR TO POWDER COAT, ALIGN B67-43001-97 ON B67-43001-357 AS SHOWN AND DRILL A $\phi 0.129$ HOLE THROUGH BOTH PARTS. FASTEN B67-43001-97 TO B67-43001-357 USING MS171534 SPRING SLOTTED PIN.
- 9) MASK PRIOR TO POWDER COAT
- 10) BEFORE OR AFTER POWDER COAT, DRILL A $\phi 0.129$ HOLE IN B67-43001-357 TO INSTALL THE LANYARD. DRILL THROUGH ONE WALL ONLY. AFTER POWDER COAT, INSTALL 30345T21 LANYARD ON B67-43001-357 AS SHOWN USING CR3213-4 TYPE RIVET AND NAS1149DN632J WASHER.

RELEASED
2016-11-09

APPROVED

DESIGN	RW	DART AEROSPACE LTD	
DRAWN	SAD	HAWKESBURY, ONTARIO, CANADA	
CHECKED	MB	DRAWING NO.	REV. D
MFG. APPR.	DD	B67-43001-45	SHEET 2 OF 2
APPROVED	WM	TITLE	SCALE
DE APPR.	N/A	LONGITUDINAL SUPPORT	NTS
DATE	16.10.17	COPYRIGHT © 1995 BY DART AEROSPACE LTD	
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.			